

DuraSystem®

安装说明

Mounting instructions

操作板 A1

Actuator plate A1











安装, Installation








4







设置, Settings

7






X	A B C
15 - 35 mm	A
36 - 70 mm	B
71 - 80 mm	C







18




19




20




21


















22



23







DURAVIT AG
P.O. Box 240
Werderstr. 36
78132 Hornberg
Germany
Phone +49 78 33 70 0
Fax +49 78 33 70 289
info@duravit.com
www.duravit.com

